



Create folder EMR with two sub folders EMR_WORKLIST and EMR_STORAGE.

In Forum go to EMR configuration.



Set path to EMR and check Activate EMR Interface. DO NOT check Limit Storage.



This only needs to be set on the machine running FORUM Server.

Share the EMR folder over the local network. For every machine, the path in CPM->AdminPage->Integrations->ZF->EMR Path TextBox would be the network path to that folder (i.e. [\\ComputerName\emr](#)).